

- Cấu hình IP cho máy tính như bên dưới: IP - 129.0.0.2/255.255.255.0 hoặc 192.168.0.2/255.255.255.0
- Kết nối máy tính vào cổng **ETH/OAM** của thiết bị bằng cáp ethernet.
- Kiểm tra kết nối đã thông chưa: ping 129.0.0.1 hoặc 192.168.0.1

Xem license

Xem Version

Get file cấu hình

Set cho file cấu hình chạy

Get Sw

Get Path

Set cho sw chạy

Set cho path chạy

Show lại

Xóa file cũ

Check CS port

Check CS port

display license

display version

tftp 192.168.0.2 vpn-instance __LOCAL_OAM_VPN__ get vrpcfg.cfg

startup saved-configuration vrpcfg.cfg

reboot

tftp 129.0.0.2 vpn-instance __LOCAL_OAM_VPN__ get ATN910C910D-V300R006C10SPC300.cc

tftp 129.0.0.2 vpn-instance __LOCAL_OAM_VPN__ get ATN910CV300R006SPH020-C10SPC300.PAT

startup system-software ATN910C910D-V300R006C10SPC300.cc all

startup patch ATN910CV300R006SPH020-C10SPC300.PAT all

dis startup

delete /unreserved ATN910C-V300R006C00SPC300.cc

check startup next

display license resource usage port-basic all

display int GigabitEthernet0/2/0 | inc Rx|Tx

display int GigabitEthernet0/2/1 | inc Rx|Tx